



Poly 686 Dry Polymer Mixing Formula

For thorough mixing use mechanical mixing device such as a drill with paddle.

Stamp Mix or Texture

- Mix 1 lb Dry Poly 686 with 4 to 6 quarts of water.
- Add in 50 lbs cement sand mixture. (Should resemble consistency of a milkshake)

Bond Coat

- Mix 2 lbs Dry Poly 686 with 4 to 8 quarts of water.

*Recommended usage levels are 5-15% polymer per parts 100 cement. The higher the polymer level the better the flexural strength, lower water absorption and improved adhesion. Anything above or below this recommendation could jeopardize the integrity of the mixture. Using too much polymer could cause latex to bleed to the surface, a drop in adhesion, long set times, etc.

Caution: These are standard mixing procedures. Any polymer wet or dry should first be tested in the mixture before use on a given job. Feel free to contact Marty with any questions. (702) 279-3282

Important Notice to Purchaser

All products manufactured by Performance Polymers LLC are made in the USA.

6639 Schuster St., Las Vegas, NV 89118

TO ORDER CALL: 800-983-6993 • Fax: 702-252-3423 • www.concreteoverlaypolymer.com

Materials are guaranteed with respect to uniformity and quality within manufacturer's specifications. Seller makes no other warranty, expressed or implied, regarding the use of its products. Since use of the product is beyond the Seller's control, the Buyer assumes all risk of use. Seller's sole obligation shall be to replace material if found to be defective. Seller shall not be liable for any damage, injury, loss, direct or consequential resulting from the use of its products.